

This document provided by



**Geek Must Have**

<https://GeekMustHave.com>

**Web**

<https://YouTube.com/c/GeekMustHave>

**YouTube**

<https://GitHub.com/GeekMustHave>

**GitHub**

# Otto One Robot GMH Notes

John HR Schuster

Version 2.1d, 01/30/2022: Notes

# Table of Contents

1. Introduction .....	3
2. Construction .....	3
3. Wiring .....	5
4. Programming .....	6
4.1. Arduino .....	6
4.1.1. Determine and set Comm port .....	7
4.1.2. Sample Arduino Script .....	7
4.2. Servo Alignment .....	9
4.3. Blockly .....	9
5. Bluetooth .....	10
6. References .....	11
7. Files .....	12
8. ASC Doctor Markdown .....	12
9. Document History .....	13

Otto Plus builder construction, programming and expansion notes. This is not a **How To** guide it is a set of notes to help when this project is referenced in the future.

To view a PDF version of this document click this [Link](#)

The GitHub Repository is located at this [Link](#)


The GeekMustHave Blog Post (where all the Videos and files are available) is located at this [Link](#)



When viewing this from GitHub there will be **No** embedded videos.



When viewing this from GitHub some of the local files and videos may **not** be available because they are too large.



# 1. Introduction

This is the first project for 2022. Happy New Year, hopefully we will be out of the Human Malware (Covid-19).

The how to build videos and examples were a bit difficult to understand. There didn't appear to be any reference to the Microphone and Bluetooth modules.

A Otto repository was created to capture everything about Otto in one place. This will include PDF rendered documents, YouTube Videos and software libraries.

## 2. Construction

This is not a 2 hour build, it is more like a 3-4 day build.

The screwdriver provided with the kit is nice but you might need the following

- Diagonal cutter, flush cut
- Rotary Tool
- Extra screws (They seem to vanish into another dimension)
- Hot glue
- UV Glue
- Hobby knife
- Hammer (Utter frustration)

Some observations on the construction

- Test fit **ALL** parts like buzzer, on/off switch. There will be sanding or dremel required
- Trim and clean up all the 3d printed parts, it will go much easier later
- Build the bottom first, align the servos
- Enlarge the holes for the power jack and USB jack, they do not align easily
- Get a better screwdriver or end up with a lot of useless phillips head screw difficult to get out
- Test fit the motor control board into the case with **NO** jumpers attached
- Touch sensor needs to be installed, taped in place, before fitting motor controller board
- Testing the alignment may cause a leg to get stuck and in turn strip the servo arms.

Some of the modifications done

- Made the jumpers between the bottom and top longer to make wiring simpler and more reliable
- Glue (UV Glue for me) the jumpers to the Piezo speaker
- Place the Bluetooth module on top of the Motor controller board
- Glue (UV Glue) the power switch, Test it first before glueing, I destroyed the switch that came

with the kit

- Test the Motor control board with just the servos attached, do alignment, then wire the rest of the modules

The following videos from Robot Creation are very useful in the build process.

▶ <https://www.youtube.com/watch?v=fxjK85jrM7k> (YouTube video)

*Robot Creations Part 2 of 4*

The video above can be viewed offline from this [Otto servo positioning](#)

▶ <https://www.youtube.com/watch?v=bzleDyvgUiw> (YouTube video)

*Robot Creations Part 3 of 4*

The following are segments of videos that help in some critical tasks

▶ <https://www.youtube.com/watch?v=fxjK85jrM7k> (YouTube video)

*Board and boot loader settings*

▶ <https://www.youtube.com/watch?v=bzleDyvgUiw> (YouTube video)

*Right/Lift orientation*

### 3. Wiring

## The Otto Plus has two extra modules

1. Bluetooth communication
2. Microphone

One of the frustrating things was the locating the wiring diagram for these two modules.

The diagram was located in the V10 construction Guide, which is at this offline [link](#)

The actual wiring diagram is on page 18.



Figure 1. Otto Plus Wiring

## 4. Programming

Otto can be programmed using Arduino or Blockly (GUI), started with Arduino because I'm a masochist.

Blockly is a great alternative if you are not comfortable with Arduino, just be prepared for many of the example **sketches** to not work properly.

Blockly sketches can be viewed and copied as the Arduino C++ code, and used directly in the Arduino IDE.

### 4.1. Arduino

The most current version of the Arduino IDE as of this document date is 1.8.19 and can be downloaded from this [Link](#)

To download the most current version of the Arduino IDE use this web [Link](#)

In order to use Arduino to upload code to Otto the Arduino libraries need to be installed.

There is a video on **How to Calibrate Otto DIY** outlines the Arduino libraries process. Unfortunately the Zip file discussed in this video has not been located.

The **How to Calibrate Otto DIY** video can be viewed or downloaded from this link::<https://pwc-lms.com/OpenStuff/BlogPosts/OttoPlus/videos/CalibrateOtto.mp4>[Video Link, window="\_blank"]

► <https://pwc-lms.com/OpenStuff/BlogPosts/OttoPlus/videos/CalibrateOtto.mp4> (video)

*Calibrate Otto*

Download the **latest** version of the Otto library from GIT at this [Link](#)

There is a local copy of the Arduino library in these notes at this [Link](#)

1. Download the .zip Otto libraries here [Download](#)
2. Open Arduino IDE and navigate to Sketch → Include Library → Add .ZIP Library. At the top of the drop down list, select the option to **Add .ZIP Library**
3. You will be prompted to select the library. Navigate to the .zip file's location, that you just downloaded and open it.
4. In the main window you will see in the bottom back area a message that it has been installed.
5. To verify they are properly installed, go to Sketch → Include Library menu. You should now see the library at the bottom of the drop-down menu That means is ready to use Otto example codes! you can find them in File → Examples → OttoDIYLib for more details or other way to install libraries visit this link



Set the device to **Arduino Nano** for Otto.





The Boot loader is the AtMega 328 (Old Boot loader) because the mini in Otto is a clone.

#### 4.1.1. Determine and set Comm port

The Arduino IDE when used with the USB Port is assigned to a Comm port.

Open the Device Manager and then click on the **Ports (Comm & LPT)** there may be some ports already assigned to other serial devices.

Plug in Blockly to a USB port, listen for the Window beep acknowledging Blockly, and watch the **Ports (Comm & LPT)** for a new comm port to be assigned.




Figure 2. Ports

#### 4.1.2. Sample Arduino Script

There is a very small script that will cycle the Servos, this is like a confidence script that the Nano is working and the code is getting loaded.

### Sample servo test

```
/*
base info from https://www.arduino.cc/en/Reference/Servo
test sketch made by Nicu FLORICA (niq_ro) for verify position for Otto legs
*/
#include <Servo.h>

Servo myservo1; // create servo object to control a servo 1
Servo myservo2; // create servo object to control a servo 2
Servo myservo3; // create servo object to control a servo 3
Servo myservo4; // create servo object to control a servo 4

int minim = 10;
int maxim = 170;

void setup() {
  myservo1.attach(2); // attaches the servo on pin 2 to the servo object 1
  myservo2.attach(3); // attaches the servo on pin 3 to the servo object 2
  myservo3.attach(4); // attaches the servo on pin 4 to the servo object 3
  myservo4.attach(5); // attaches the servo on pin 5 to the servo object 4

  myservo1.write(minim); // sets the servo 1 position
  myservo2.write(minim); // sets the servo 2 position
  myservo3.write(minim); // sets the servo 3 position
  myservo4.write(minim); // sets the servo 4 position
  delay(3000);
  myservo1.write(maxim); // sets the servo 1 position
  myservo2.write(maxim); // sets the servo 2 position
  myservo3.write(maxim); // sets the servo 3 position
  myservo4.write(maxim); // sets the servo 4 position
  delay(3000);
}

void loop() {

  myservo1.write(90); // sets the servo 1 position
  myservo2.write(90); // sets the servo 2 position
  myservo3.write(90); // sets the servo 3 position
  myservo4.write(90); // sets the servo 4 position

}
```

A offline copy of the servo test can be downloaded from this [link](#)

This test will move the servos to the Left, then to the right, then back to center.



This script could cause the legs to rotate to far to the left or right causing the servo arm to get stripped. PITA.

## 4.2. Servo Alignment

Alignment is **Critical!!**, this step can **not** be skipped.

The legs are aligned separately from the feet.

After the alignment of the legs/Feet are complete the setting must be written into memory, so when the Otto is restarted it has the proper **Home** position.

## 4.3. Blockly

There are two **BLOC** example scripts to help test the assembled Otto.



These two scripts are in the **Examples** of Blockly

**Alignment Serial** - Align the legs and feet and write the settings into Otto memory. These settings are used to set Otto to default home position when a new BLOC is started.

**Alignment Walk** - Test Otto walking, check Otto walks straight as possible.

There are other BLOC's to test the Piezo speaker, touch sensor and the ultrasonic sensor

The Dance BLOC is a very good script to show Otto dancing, great way to check Otto working

By combing the Dance, touch sensor and Piezo BLOCs together the BLOC below was designed.

*BLOC Diagram*



This OTTO BLOC can be downloaded from this [Link](#)

When the BLOC is converted to C++ to Otto it looks like

## 5. Bluetooth

A special Arduino script is required for using the OTTO app on the cellphone.

### *Bluetooth Script*

Insert code here

The OTTO app must be downloaded into the phone. This app has functions to do movements, play sounds, and if an LED matrix is attached show emoticons. The code examples can be used to integrate Bluetooth into new scripts.

There is an Arduino script to upload to OTTO, which will enable the Bluetooth function.

It is located in the Arduino examples under OttoDIYLib / Bluetooth / Otto\_PLUS\_APP\_V9.ino.

There is also a Blockly BLOC for testing the bluetooth functions.

► <https://www.youtube.com/watch?v=OVXpNzEQ2tE> (YouTube video)

### *Bluetooth Setup*

### *Dance script C++*

```
include:files/xyyyzzdummy.txt
```

## 6. References

How to customize the physical Otto [4 easy ways to design your own robot](#)

## 7. Files



Not all of the file in the table below will be available from the GitHub site as there is a 50MB limit.

Table 1. Files referenced in document

Description	Type	Download
Calibration Video	Video MP4	<a href="#">Download</a>
OTTO Arduino library	Zip	<a href="#">Download</a>
OTTO BLockly program	EXE	<a href="#">Download</a>
Arduino V1.0 IDE	EXE	<a href="#">Download</a>
OTTO Blockly requires current Java runtime	EXE	<a href="#">Download</a>
OTTO Servo test	Arduino Code	<a href="#">Download</a>
3D Printing STL file for extra body for OTTO	3D STL	<a href="#">Download</a>
Robot Creations Video Part 2 of 4	Video MP4	<a href="#">Download</a>
Robot Creations Video Part 3 of 4	Video MP4	<a href="#">Download</a>
Robot Creations Video Part 4 of 4 Best!	Video MP4	<a href="#">Download</a>

## 8. ASC Doctor Markdown

This document was created using ASCIIDoctor Markdown. More information on ASCIIDoctor can be found at <https://asciidoctor.org/>

If you are interested in the ASC Doctor (ADOC) markdown behind this document, it can be downloaded at this [Link](#)

## 9. Document History

*Table 2. Document History*

<b>Date</b>	<b>Version</b>	<b>Author</b>	<b>Description</b>
01/30/2022	V2.1d	JHRS	Updates after the rework of the construction and valid testing
01/25/2022	V2.1c	JHRS	Updates after initial construction and testing
01/13/2022	V2.1b	JHRS	Initial version